

J1
XF2M-3315-1A
epaper-breakout:CONN_ED0970C4

pin1	1	VNEG
	2	NC
pin3	3	VPOS
	4	NC
pin5	5	VSS
	6	NC
pin7	7	VDD
pin8	8	SKH
pin9	9	LEH
pin10	10	OEH
pin11	11	RL
pin12	12	STH
pin13	13	D0
pin14	14	D1
pin15	15	D2
pin16	16	D3
pin17	17	D4
pin18	18	D5
pin19	19	D6
pin20	20	D7
	21	NC
pin22	22	VCOM
	23	NC
pin24	24	VGG
	25	NC
pin26	26	VEE
	27	NC
pin28	28	MODE2
pin29	29	MODE1
pin30	30	UD
pin31	31	STV
pin32	32	SKV
pin33	33	BORDER

CASE_1 34 pin34
CASE_2 35 pin35

J2
XF2M-3315-1A
epaper-breakout:CONN_ED0970C4

pin33	1	VNEG
pin32	2	NC
pin31	3	VPOS
pin30	4	NC
pin29	5	VSS
pin28	6	NC
	7	VDD
pin26	8	SKH
	9	LEH
pin24	10	OEH
	11	RL
pin22	12	STH
	13	D0
pin20	14	D1
pin19	15	D2
pin18	16	D3
pin17	17	D4
pin16	18	D5
pin15	19	D6
pin14	20	D7
	21	NC
pin12	22	VCOM
pin11	23	NC
pin10	24	VGG
	25	NC
pin9	26	VEE
pin8	27	NC
pin7	28	MODE2
pin5	29	MODE1
	30	UD
pin3	31	STV
	32	SKV
pin1	33	BORDER

CASE_1 34 pin35
CASE_2 35 pin34

Sheet: /
File: 33pin_extension.kicad_sch

Title:

Size: A4 Date:
KiCad E.D.A. kicad-cli 7.0.11-7.0.11-ubuntu22.04.1

Rev:
Id: 1/1